

NF13-3

SET UP INSTRUCTIONS:

- 1. CONNECT BOTTOM AND TOP RAILS FOLLOWING THE LABELS
- 2. CONNECT SIDE RAILS
- 3. CLEAN THE FRAME AND PLACE THEM ON CLEAN PLACE
- 4. CAREFULLY REMOVE FABRIC COVER FROM BAG
- 5. PLACE COVER AROUND THE BOTTOM OF THE FRAME
- 6. PULL COVER CAREFULLY UP TO THE TOP
- 7. CLOSE ALL ZIPPERS
- 8. ADJUST FABRIC AROUND THE FRAME
- 9. CONNECT CABLE HARNESS TO THE EYEBOLTS


BREAK DOWN INSTRUCTIONS:

REVERSE SET-UP STEPS TO BREAKDOWN FRAME


FABRIC CARE INSTRUCTIONS:

- 1. UNZIP COVER ZIPPERS
- 2. CAREFULLY REMOVE FABRIC COVER
- 3. CLOSE ALL ZIPPERS
- 4. FOLD OR ROLL NEATLY
- 5. PLACE FABRIC IN COVER BAG


Frame parts




x4
3' Corner




x4
32" Straight Spreader




x4
8' Dia. Curve tube
w/ molded connector




x4
8' Dia. Curve tube
w/ molded connector & eye bolt



x8
8' Dia. Curve tube



x4
70" Steel wire rope



x1
Fabric Cover

Frame Assembly
Assemble frame as shown

Fabric Cover
GRAPHIC SIZE: 105 1/2" x 36"(V)
Fabric: 4417 (4) Panels
Add a 2" bleed on all sides
PILLOWCASE CONSTRUCTION