

# Neo Cord

---

When combining our frame and lens with a thin printed substrate, or should you decide not to use the provided protective lens, our neoprene insert may provide added friction between the clear lens (or graphic, if no lens is in use) and the extrusion. Simply stretch the neoprene insert as you wedge it under the extrusion using a plastic card or squeegee. Short 3" sections should be adequate.



We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.