


# 2' Height Extension Kit for Formulate Straight Frame

## FMLT-10FT-EXT-WS1010 and WS1210

Your Formulate® Display Wall conveys your message and communicates your ideas to the world but what if the standard height just isn't enough? Now you have the option to add an additional 2 feet in height to most Formulate display walls creating the ultimate impact for your brand! Make the most of your message with an easy to assemble display addition that will attract attention from across the room.



### features and benefits:

- 30mm anodized silver extrusion
- Tool-less and easy to install snap button connections
- Converts an 8ft high straight backwall kit into a 10ft high backwall
- Lifetime hardware warranty against manufacturer defects

### dimensions:

#### Hardware

Assembled unit:  
116.69" w x 28.5" h x 1.18" d  
2964mm(w) x 724mm(h) x 30mm(d)

Approximate weight:  
5 lb / 3 kg

#### Shipping

Packing case(s):  
1 CN-48-BX

Shipping dimensions:  
50" l x 6" h x 6" d  
1270mm(l) x 153mm(h) x 153mm(d)

Approximate total shipping weight:  
7 lb / 4 kg

### additional information:

When included in a larger order, a different packaging solution will be provided to accommodate all contents of the order. Individual packaging may no longer be provided.



This product may include the following materials for recycle:  
aluminum, select wood, fabric, cardboard, paper, steel, and plastics.

**1 person assembly recommended:**



We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

# Included In Your Kit



TUBE-679 x3



WS10-T2 x2



WS10-T5 x1




TC-30-T x2

Components, Connectors & Graphics


# Exploded View

FMLT-10FT-EXT-WS1010 and WS1210 EXTENSION KIT



# Exploded View

FMLT-WS10-F & FMLT-10FT-EXT-WS1010 EXTENSION KIT COMBINED




# Kit Assembly

## Step by Step

### Step 1.

Remove the top tubes and connectors as shown. Use the Exploded View for part labels.


Reference Connection Method(s) 2 & 4 for more details.



### Step 2.

Gather components to assemble FMLT-10FT-EXT-WS1010 extension kit.


Reference Connection Method(s) 1 & 3



### Step 3.

Attach FMLT-10FT-EXT-WS1010 to existing frame. Use the Exploded View for part labels.


Reference Connection Method(s) 1 & 3



### Step 4.

Attach top section as shown. Use the Exploded View for part labels.

Reference Connection Method(s) 1, 2 & 4




# Kit Assembly

## Step by Step

### Step 5.

Pull the pillowcase graphic over the frame and zipper it closed at the bottom.




### Step 6.

Setup is complete.




# Connection Methods

**Connection Method 1: TC-30-90T**




Take the plastic connector and make sure the snap buttons are in proper position for the frame tube holes. Simply press the snap button with your thumb and carefully slide the tube onto the connector. The snap button should pop through. Some twisting may be necessary to assure the snap button has popped all the way through the tube hole. Do not force the connection and be careful with the tube edges, they may be sharp.

**Connection Method 2: TC-30-T**




Take the plastic connector and make sure the snap buttons are in proper position for the frame tube holes. Simply press the snap button with your thumb and carefully slide the tube onto the connector. The snap button should pop through. Some twisting may be necessary to assure the snap button has popped all the way through the tube hole. Do not force the connection and be careful with the tube edges, they may be sharp.

**Connection Method 3: WS10-T5 & WV20-01-T2**



Take the plastic connector and make sure the snap buttons are in proper position for the frame tube holes. Simply press the snap button with your thumb and carefully slide the tube onto the connector. The snap button should pop through. Some twisting may be necessary to assure the snap button has popped all the way through the tube hole. Do not force the connection and be careful with the tube edges, they may be sharp. Repeat this process for all 4 snap buttons.

**Connection Method 4: WS10-T4**



Take the plastic connector and make sure the snap buttons are in proper position for the frame tube holes. Simply press the snap button with your thumb and carefully slide the tube onto the connector. The snap button should pop through. Some twisting may be necessary to assure the snap button has popped all the way through the tube hole. Do not force the connection and be careful with the tube edges, they may be sharp.